



# MICRO-CURE E2

## Near-wellbore remediation



MICRO-CURE™ E2 is an environmentally friendly, proprietary remediation treatment designed for cased and perforated completions. MICRO-CURE E2 eliminates common near-wellbore damage mechanisms, enabling increased production rates. It is an excellent pre-flush treatment when pumped ahead of acid and frac operations.

The application of MICRO-CURE E2 removes skin damage, water-wets and mobilizes solids particles such as asphaltene, mud solids and carbonate in the rock matrix, and eliminates emulsion damage in the near wellbore region. Treatment with MICRO-CURE enables reservoirs to flow at their maximum potential, increasing the value and return on investment for the operator.

### Recommended treatment

MICRO-CURE E2 is pre-mixed and packaged ready to pump. The treatment volume will be dependent on the total length of perforations and porosity in the near-wellbore rock matrix. MICRO-CURE E2 is a single-step application that is delivered to the damaged zone by bull heading or by using a coiled tubing unit.

Under some situations, MICRO-CURE AF E2 will be delivered to the wellsite and the acid mixed on location to maximize performance. Please consult your Baker Hughes fluids representative for your specific application's treatment requirements.

### Applications

- Cased and perforated wells
- Frac spearheading

### Benefits

- Increases flow mobility of reservoir fluids
- Removes emulsion damage
- Maximizes removal of pore-plugging particles
- Extends the production life of older wells in mature fields
- Delivers return on investment in newly drilled wells experiencing near-wellbore damage
- Provides an effective alternative to expensive re-fracturing or re-drilling

### Features

- Removes multiple forms of skin damage
- Solubilizes oil and reduces interfacial tension of fluids
- Reduces surface tension and phase trapping
- Water-wets solids in the rock matrix
- Contains no harmful solvents

## Environmental information

For additional information concerning environmental regulations applicable to this product, contact the Health, Safety and Environmental department of Baker Hughes.

## Shipping

Transportation of MICRO-CURE E2 is not restricted by international or USA regulatory agencies.

## Safe handling recommendations

MICRO-CURE E2 contains a weak organic acid. Utilize normal precautions for employee protection when handling chemical products. Use of standard personal protection equipment is recommended for employee comfort and safety. See Material Safety Data Sheet (MSDS) prior to use.

## Packaging

MICRO-CURE E2 and MICRO-CURE AF E2 are both packaged in 55-gallon (200-liter) drums and in 275-gallon (1,000-liter), 330-gallon (1,200-liter), and 550-gallon (2,000-liter) totes.

## Typical physical properties

Appearance	Translucent fluid
pH (E2)	2.58
pH (AF E2)	5.58
SG @ 68°F (20°C)	1.03-1.04
Flash point	>212°F (>100°C)
Pour point	18 ±36°F (2°C)



[www.bakerhughes.com](http://www.bakerhughes.com)

Disclaimer of Liability: This information is provided for general information purposes only and is believed to be accurate as of the date hereof; however, Baker Hughes Incorporated and its affiliates do not make any warranties or representations of any kind regarding the information and disclaim all express and implied warranties or representations to the fullest extent permissible by law, including those of merchantability, fitness for a particular purpose or use, title, non-infringement, accuracy, correctness or completeness of the information provided herein. All information is furnished "as is" and without any license to distribute. The user agrees to assume all liabilities related to the use of or reliance on such information. BAKER HUGHES INCORPORATED AND ITS AFFILIATES SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, PUNITIVE, EXEMPLARY OR CONSEQUENTIAL DAMAGES FROM ANY CAUSE WHATSOEVER INCLUDING BUT NOT LIMITED TO ITS NEGLIGENCE.